cura1.com
1300 12 2273

2581 Pager With Numeric Display, Vibrate Option and 11 Language Selection

Quick Start Guide

Optional Accessories (Sold Seperately)


#2600 - 30 Channel Display Panel


#2583 - Pager Signal Extender

2581 Pager With Numeric Display, vibrate option and 11 language selection

Wireless Radio Pager with LCD display. 30m receiving range. Multilingual voice messaging / tones. Vibrate Option. On/off switch. Belt Clip. Powered by two AA batteries.

Pager Setup

Insert 2 x AA batteries into the battery compartment.

Turn on the Pager using the button on the right hand side. The button can be in the one of 3 positions: Off, Vibrate or Normal.

Make sure the “Unlock / Lock” switch inside of the Pager battery compartment is in the *“Unlock”* position.

Press the “Language” button on the front of the Pager repeatedly until you find the alarm tone or message you prefer.

Press the “Volume” button on the front of the Pager repeatedly until you find the alarm volume level you prefer.

Change the “Unlock / Lock” switch inside of the battery compartment to the “Lock” position. This will prevent any changes being made to the settings that have been programmed (except volume).

Pager Operation

The “Review” button on the front of the pager will allow you scroll back through the last 6 alarm messages.

The LCD display on the front of the Pager will display the *identity number* of the Wireless Alarm Transmitter that caused the alarm to occur.

To reset the Pager, the alarm condition must be reset from the 2600 ActiveAlert display panel.





