

• Up to 1.5km range • No structural cabling required • Database logging • Duress location finding - zones • Mobile phone notifications • Pager notifications • Email notifications • Can monitor up to 3,072 devices	**2502MC CentreCall Master Zone Repeater (Wireless 900 / 433Mhz)** The 2502MC CentreCall Master Zone Repeater is the heart of the CentreCall System. CentreCall requires no structural cabling and boasts a range of up to 1.5km, suitable for CentreCall can be as large or as small as required with a capacity of up to 48 Slave Zone Repeaters each handling up to 64 portals.	

			12 Month Warranty
2509C	CentreCall Software		Highly useful software for managing calls, logs all events into a database which can be easily searched by date / time, staff can enter tenancy/ client details which can be displayed with specific alarms.
2502MC	LRCS Master Zone Repeater (Wireless 900 / 433Mhz)		Receives signals from the 2502SC Slave Zone Repeaters and communicates directly with 2509C CentreCall Software.
2502SC	CentreCall Slave Zone Repeater (Wireless 900 / 433Mhz)		Fully transparent to all CentreCall compatible equipment, repeats signal and boosts range, optional backup battery pack product code 2508.
2503C	CentreCall Portal		Battery powered* & fully supervised wireless operation. Calls for: “Security”, “Medical”, “Maintenance” and “Cleaners”. Features LED call reassurance indicators. *Can also be hardwired to an external 12V DC power supply.
2595	Wristband Alarm Transmitter		Can be worn on the wrist of staff to be used to raise an alarm.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2547	POCSAG VHF Paging Transmitter		Programable power output. Programable operating frequency. Over temperature cutout. Connects directly to PC running the 2509C CentreCall Software.
2548	POCSAG VHF Alphanumeric Pager		4 line, 84 character display. Easy to read back lit display. Time & date display 12 or 24 hour clock. Message time & date stamping.
2404	cura1 12V Plug Pack		Power Adaptor suitable for 2502 Zone Repeaters, 2504, 2547, 2512, 2513.
2642	Caregiver Reset Key		Allows caregivers to reset 2503 Portal alarms. Allows authorised staff to program various cura1 equipment. Key chain can be attached to belt or clothing. Lightweight.
2589	White Buckle Wrist Strap		Removable via buckle straps for use with the 2595 Wristband Alarm Transmitter.
2567	Lanyards with Safety Break Clip		Alternative option for 2595 Wristband Alarm Transmitter.
2512	LED POCSAG Display Single		Bright LED display with high visibility, adds an extra safety measure assuring that staff will see an alarm / call.
2513	LED POCSAG Display Double		Bright LED display on both sides with high visibility, adds an extra safety measure assuring that staff will see an alarm / call.
2507	Wireless Waterproof Callpoint		With a battery life of one year* depending on frequency of usage, communicates a call to Slave Zone Repeater, features an integral pullcord and RED LED call reassurance indicator for added safety. *Battery is replaceable

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2504	Multi-coloured Overdoor Light		Highly visible LED indicators showing call priority. Features a distinct audible alarm, can be paired with up to ten 2503 Portal's or Waterproof Call Button's. Acts as a wireless signal repeater.
2522	System Programmer		Essential tool for programming 2503 CentreCall Portal & 2504 Multi-coloured Overdoor Light.
2502P	Easy Programmer		Essential tool for programming 2503 CentreCall Portal & 2507 Waterproof Callpoint's. Connects directly to installers PC via serial programming cable that is included.
2602	USB-A to RS232 Serial Converter		Use to connect 2502MC Master Zone Repeater to a PC or Laptop
2533	LRCS 4 Way Relay Board		Provides a low level hardwired interface to third party equipment, can be wired to trigger security alarms, CCTV, building automation, access control and anything that accepts a relay input. This board can be assigned in software to activate specific relays under certain conditions providing either an NC or NO output (selected by hardware) that provides a momentary relay
2698	Universal Transmitter		Turn any third-party alarm device into a wireless transmitter. Can also be used as a wireless door contact. Communicates directly 2502SC Slave Zone Repeater.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.