• Large 7 character numeric / limited alpha digital display • Red reminder LED • Simple programing • Selectable OFF / Vibrate / Vibrate +Tone • Alarm mute facility with auto reminder vibrate until alarm canceled • Alarm review via menu button • Selectable alarm cancel • Includes belt clip • Optional wall bracket available		Self Reset	**3501 ActiveCare Pager Compatability Matrix** Ideal for private homes, shared care homes, surgeries or small care facilities, and larger facilities when paired with the 3500 ActiveCare Console **What's in the box:** 1 x 3501 ActiveCare LCD Pager 1 x Quick Start Guide 2 x High Quality AA Batteries	
				12 Month Warranty
3515	Cordless Under Mattress Bed Pad 1 Year (830 x 260)	✓		Place **UNDER THE MATTRESS** Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via [Device] ****Requires 2719 Transmitter to function****
2629	Cordless Bed Pad 1 Year (760 x 500)	✓		Place **ON TOP OF THE MATTRESS**. Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via [Device]. ****Requires 2719 Transmitter to function****
2630	Cordless Chair Pad 1 Year (380 x 250)	✓		Sends **OUT OF CHAIR** message when getting out of chair. Resets **OUT OF CHAIR** when back on chair or via [Device]. ****Requires 2719 Transmitter to function****
2624	Cordless Floor Mat 1 Year (1220 x 620)			Position in an area of **FALLS RISK**. Initiates alarm when **stepped on**. Reset the alarm via [Device]. ****Requires 2719 Transmitter to function****
2719	Cordless Pad Transmitter			Required by Cordless Pads/Mats. Sends a signal to the 3501 OR Sends a signal to whichever device it is programmed to (2700, 3500, 2544, 2549) ****1 year battery life. Replace the transmitter after one year****
2670	Cordless PreAlert Bed Pad 1 Year (830 x 260)	✓		Located on **TOP OF THE MATTRESS**. Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via 3508 Pager.
2588	PET (Personal Emergency Transmitter)			Initiates alarm when **RED Button** is pressed. Reset on Pager.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2721	iBeam			Sends alarm when triggered. Features a narrow detection zone to reduce false alarms, triggers when a patient breaks the beam. Reset on Pager.
2595	Wristband Alarm Transmitter			Staff or patients wear on the wrist. Use as a duress alarm or call button. Initiates alarm when **RED Button** is pressed. Reset on Pager.
2599	Wireless SOS Call Button			Wall mountable emergency call point. Initiates alarm when **RED Button** is pressed. Reset on Pager.
3502	ActiveCare Wireless Handset (includes wall bracket)	✓		Initiates alarm when **RED button** is pressed. Includes **GREEN** wireless reset button or reset via Pager.
3503	Wireless Door Contact			Sends alarm when door is **opened**. Can also be used as a simple **push button** call point. Reset on Pager.
2698	Universal Transmitter	✓		Turn any third-party alarm device into a wireless transmitter. Can also be used as a wireless **door contact**. Togglable **Reset** button.
2558	Wireless Waterproof Call Button w/pullcord	✓		Initiates alarm when **RED button** is pressed or **cord is pulled**. Includes wireless **reset button** or reset on **[Device]**
2900	DoorAlert+ Door Monitor	✓		Identifies when a resident approaches or exits a door if they are wearing a **2901 Wristband Transmitter**. ****See 2900 DoorAlert+ Compatibility Matrix for products required / optional****
2901	Resident Wristband Transmitter			Identifies when a resident approaches or exits a door protected by **2900 DoorAlert+ Door Monitor**. Resident wears on wrist or with a lanyard. ****See 2567 Lanyard w/ Safety Break Clip for lanyards****
3504	Mounting Bracket			Pager slides into bracket. Bracket mounts onto surfaces with **double-sided tape** or **M3 screws**.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

3506	ActiveCare Pager Soft Cover			Optional soft touch removable protection case provides extra protection for the **3501 Pager**.
3500R	ActiveCare Monitor	✓		Mount on a wall or desk. Alarms on its seven-segment display and plays an audible adjustable tone. Can be paired with the **3501** Pager and up to two extra **3500R** ActiveCare Monitors acting as slaves to expand signal range by 50m. ****See 3500R ActiveCare Monitor Compatibility Matrix for products required / optional****
2700	Six Channel Cordless Falls Monitor	✓		Mount on a wall in or desk. Alarms on its seven-segment display and plays an audible adjustable tone. Can plug into a nurse call system. Reset on Falls Monitor will reset Pagers. ****See 6 Channel Cordless Falls Monitor Compatibility Matrix for products required / optional****
2703	Wireless Output Falls Monitor	✓		Monitor corded pads and mats. Turns any corded pad or mat into a cordless device. No need for a cordless pad transmitter. ****See Wireless Output Falls Monitor Compatibility Matrix for products required / optional****
2730	SnapOn Bed Pad 1 Year (800 x 255)			Place **ON TOP OF THE MATTRESS** Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via connected monitor. ****Requires 2732 SnapOn Pad Transmitter to function****
2731	SnapOn Chair Pad 1 Year (420 x 180)			Sends **OUT OF CHAIR** message when getting out of bed. Resets **OUT OF CHAIR** when back in bed or via connected monitor. ****Requires 2732 SnapOn Pad Transmitter to function****
2732	SnapOn Pad Transmitter			Required by SnapOn Pads. Sends a signal to the 3501 Pager. ****Replaceable CR2045 battery.****

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2690	Universal Single Fold Bed Pad 18 Months (760 x 255)	✓		Place **ON TOP OF THE MATTRESS** Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via 2700 Falls Monitor. ****Requires 2720 Transmitter to function****
2689	Universal Under Mattress Bed Pad 18 Months (830 x 260)	✓		Place **UNDER THE MATTRESS** Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via 2700 Falls Monitor. ****Requires 2720 Transmitter to function****
2691	Universal Chair Pad 18 Months (380 x 255)	✓		Sends **OUT OF CHAIR** message when getting out of chair. Resets **OUT OF CHAIR** when back on chair or via 2700 Falls Monitor. ****Requires 2720 Transmitter to function****
2692	Universal Floor Mat 18 Months (1220 x 610)			Position in an area of **FALLS RISK**. Initiates alarm when stepped on. Reset the alarm via 2700 Falls Monitorr. ****Requires 2720 Transmitter to function****
2720	Universal Cordless Pad Transmitter			Required by Universal Pads / Mats if not connected via lead. Sends a signal to the 2700 Falls Monitor. ****18 month battery life. Replace the transmitter after 18 months****
2669	Cordless Under Mattress PreAlert Bed Pad 1 Year (820 x 240)			Place **UNDER THE MATTRESS** Sends **OUT OF BED** message when at edge of bed. Resets **OUT OF BED** when back in bed or via 2700 Falls Monitor

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.