Universal Transmitter



PART NUMBER: **2698**

FEATURES

Use of your own third party NC / NO device

Screw terminal allows input for external alarm reset

Rapid, low cost, user friendly setup requires no cabling or specialist programming

Included magnetic switch for protecting doors, windows, fridges, cupboards - anything that opens

Button provides reset, pause or escort functionality

Button can be disabled

2 colour (red / green) status LED

Fully supervised wireless signal - reports low battery and device lost, making it suitable for critical applications

Secure reset - disables the front reset button (requires caregiver key)

Tamper protection causes alarm if casing is opened

Double sided tape included for easy mounting

TECHNICAL SPECIFICATIONS

Radio frequency: 433.92 MHz

Operating range: 50* m

Power: 3 V CR2477 lithium-ion battery (changeable)

Dimensions: 80 x 41 x 19 mm

Housing material: ABS

Net weight: 50 g

Operating temp.: 5°C to 40°C

Battery Life: 1 year (nominal)

Rel. humidity: < 90%

ACCESSORIES

The 2698 Universal Transmitter must be paired with at least one of the following devices:
2700 Six Channel Cordless Falls Monitor, **3500R** ActiveCare Monitor, **3501** ActiveCare Pager, **3508** LED Pager, **2544** & **2549** Cordless Multiport Expanders, **2561** Wireless Indicator Light, **2502s** Slave Zone Repeater

cura1.com

*The range of wireless devices may vary and be dependent on your specifc environmental conditions.
cura¹ products are designed to augment well designed care programs and practices, cura¹ does not claim that any of its products are suitable as a substitute, or as a total solution for individuals that require care and constant supervision, and are at risk.

PM121