• Battery backup
• Wall or desk mount
• Large 2 digit display
• Simple Programing (w/lock switch)
• 60 inputs - Each input can indicate calls from
  • Bed / Chair / Mat Alert
  • Emergency Button
• Separate indication for Door Alert and reporting up to 16 doors
• Selectable "signal lost" supervisoin (tracking) of Bed / Chair / Mat Tx's.
• Volume
• Front panel alarm reset
• Can operate with up to 2 slave 3500 ActiveCare Consoles
		Self Reset	**3500 ActiveCare Console Compatability Matrix**
			
			Suitable for shared care homes, sugeries, small care facilieis, and larger facilities when paired with the 3551 Pager and up to 2 more 3500 Consoles.
			
			What's in the box:
			1 x 3500 Console
			1 x Quick Start Guide
			1 x 2404 12V DC Regulated Plug Pack
			6 x High Quality AA Batteries
				

				3500 ActiveCare Console
3501	ActiveCare Pager	Y		Reports all alerts on a limited alpha / numeric 7-character screen. Allows for staff mobility. Optional 3504 Bracket Mount available.
3515	Cordless Under Mattress Bed Pad	Y		Located UNDER MATTRESS. Sends OUT OF BED message when getting out of bed. Resets OUT OF BED when back in bed.
2629	Cordless Bed Pad	Y		Sends OUT OF BED message when getting out of bed. Resets OUT OF BED when back in bed.
2630	Cordless Chair Pad	Y		Sends OUT OF CHAIR message when getting out of chair. Resets OUT OF CHAIR when back on chair.
2624	Cordless Floor Mat			Sends message when stepped on. Reset at console.
2719	Cordless Pad Transmitter			Required by Cordless Pads/Mats, sends a signal to the 2501, 2544, 2549, 2700, 3500, 3501.
2588	PET (Personal Emergency Transmitter)			Sends message when RED button pressed, reset at console.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2721	iBeam			Sends alarm message when triggered. Features a narrow detection zone to reduce false alarms. Ttriggers when a patient breaks the beam.
2723	EzyStand			EzyStand can be installed adjacent to a bed or chair, or across a doorway. With our sturdy, adjustable-height EzyStand, precise positioning of the iBeam could not be simpler.
3502	ActiveCare Wireless Handset (Includes wall bracket)			Sends message when RED button pressed. Reset at console.
3503*	Simple Push Button Call Point*			Sends message when White button pressed. Reset at console.
3503	ActiveCare Magnetic Reed Switch			Sends message when door opened. Reset at console.
2558	Wireless Waterproof Call Button w/pullcord			Sends message when button is pressed or cord is pulled. Reset at console or by 2559 Reset Button.
2559	Wireless Waterproof Reset Button			Resets messages initiated by 2558 Call Button.
2404	cura1 12V Plug Pack			Plug Pack included with 3500 console.
2552	Door Alert Strip Receiver			Detects wandering residents wearing 2572 Wristband Transmitters.
2572	Resident Wristband Transmitter			Used with 2552 DoorAlert Strip Rx.
2575	Caregiver Reset Transmitter			Cancels alarms at DoorAlert Strip.
2642	Caregiver Reset Key			Cancels alarms at DoorAlert Strip.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.