Up to 1.5km range No structural cabling required Database logging Duress location finding - zones Mobile phone notifications Pager notifications Email notifications Can monitor up to 3,072 devices		**2502M LRCS Master Zone Repeater (Wireless 900 / 433Mhz)** The 2502M LRCS Master Zone Repeater is the heart of the Long Range Call System. LRCS requires no structural cabling and boasts a range of up to 1.5km, suitable for residential / independent living, nursing homes, facilities, staff duress and more! The LRCS can be as large or as small as required with a capacity of up to 48 Slave Zone Repeaters each handling up to 64 call points.	
			12 Month Warranty
2509	LRCS Database Software		Highly useful software for managing calls, logs all events into a database which can be easily searched by date / time, staff can enter patient details which can be displayed with specific alarms.
2502M	LRCS Master Zone Repeater (Wireless 900 / 433Mhz)		Receives signals from the 2502S Slave Zone Repeaters and communicates directly with 2509 LRCS Database Software.
2502S	LRCS Slave Zone Repeater (Wireless 900 / 433Mhz)		Fully transparent to all LRCS compatible equipment, repeats signal and boosts range.
2503	Combo Callpoint		Battery powered* & fully supervised wireless operation. Four levels of call priority: “Call”, “Staff”, “Emergency” and “Presence”. Features RED LED call reassurance indicators for added safety. *Can also be hardwired to an external 12V DC power supply.
2506	Pendant Callpoint with RJ11 Plug		Optional extra for the 2503 Combo Callpoint, adds a handset that triggers a call, useful if the Callpoint is going to be mounted bedside.


All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2507	Wireless Waterproof Callpoint		With a battery life of one year* depending on frequency of usage, communicates a call to LRCS Slave Zone Repeater, features an integral pullcord and RED LED call reassurance indicator for added safety. *Battery is replaceable
2504	Multi-coloured Overdoor Light		Highly visible LED indicators showing call priority. Features a distinct audible alarm, can be paired with up to ten Combo or Waterproof Callpoints. Acts as a wireless signal repeater.
2596	Wireless Callpoint with RJ10 Input		Battery powered* curtailed alternative to 2503. Three levels of call priority: “Call”, “Emergency”, “Presence”. Features RED LED call reassurance indicators for added safety. *Battery is replaceable
2597	Pendant Callpoint with RJ10 Plug		Triggers a call, useful if the call button is going to be mounted bedside. Plugs directly into 2596 Wireless Waterproof Call Button RJ10 connection.
2547	POCSAG VHF Paging Transmitter		Programable power output. Programable operating frequency. Over temperature cutout. Connects directly to PC running the 2509 LRCS Software.
2548	POCSAG VHF Alphanumeric Pager		4 line, 84 character display. Easy to read back lit display. Time & date display 12 or 24 hour clock. Message time & date stamping.
2404	cura1 12V Plug Pack		Power Adaptor suitable for 2502M, 2502S, 2502P, 2504, 2547, 2512, 2513.
2642	Caregiver Reset Key		Allows caregivers to reset LRCS cura¹ equipment alarms. Allows authorised staff to program various cura1 equipment. Key chain can be attached to belt or clothing. Lightweight.
2595	Wristband Alarm Transmitter		Can be worn on the wrist of staff or patients to be used as either a duress alarm or call button. Communicates directly 2502S Slave Zone Repeater.


All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2698	Universal Transmitter		Turn any third-party alarm device into a wireless transmitter. Can also be used as a wireless door contact. Communicates directly 2502S Slave Zone Repeater.
2589	White Buckle Wrist Strap		Removable via buckle straps for use with the 2595 Wristband Alarm Transmitter.
2567	Lanyards with Safety Break Clip		Alternative option for 2595 Wristband Alarm Transmitter.
2700	6 Channel Cordless Falls Monitor		Can be mounted on a wall in or outside the patient's room. Alarms on its bright, visible seven-segment display, plays an audible adjustable tone and can be plugged into a nurse call system. Communicates directly 2502S Slave Zone Repeater.
3515	Cordless Under Mattress Bed Pad (830 x 260)		Located UNDER MATTRESS Sends OUT OF BED message when getting out of bed. Resets OUT OF BED when back in bed or via Monitor. *Requires 2719 Transmitter to function*
2629	Cordless Bed Pad (760 x 500)		Sends OUT OF BED message when getting out of bed. Resets OUT OF BED when back in bed or via Monitor. *Requires 2719 Transmitter to function*
2630	Cordless Chair Pad (380 x 250)		Sends OUT OF CHAIR message when getting out of chair. Resets OUT OF CHAIR when back on chair or via Monitor. *Requires 2719 Transmitter to function*
2624	Cordless Floor Mat (1220 x 620)		Positioned strategically in an area of risk. Initiates alarm when stepped on. Reset on Falls Monitor. *Requires 2719 Transmitter to function*
2719	Cordless Pad Transmitter		Required by Cordless Pads/Mats. Sends a signal to the 2700. *1 year battery life*

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2900	DoorAlert+ Strip Door Monitor		Communicates directly with 2502S LRCS Slave Zone Repeater's expanding its functionality, adds a secure way to monitor when patients access specific areas. Highly suitable for dementia wards and wandering residents. Can be connected to an electric lock to automatically lock doors.
2901	Resident Wristband Transmitter		Resident wears on wrist or with a lanyard. Identifies when a resident approaches or exits a door that is protected with a 2900 Door Monitor.
2569	Wrist Straps		Replacement wristband straps for Resident Wristband Transmitter.
2575	Caregiver Reset Transmitter		For use by caregivers to reset 2900 Door Monitor alarms remotely.
2512	LED POCSAG Display Single		Bright LED display with high visibility, adds an extra safety measure assuring that staff will see an alarm / call.
2513	LED POCSAG Display Double		Bright LED display on both sides with high visibility, adds an extra safety measure assuring that staff will see an alarm / call.
2522	System Programmer		Essential tool for programming 2503 Combo Callpoints & 2504 Multi-coloured Overdoor Light.
2502P	Easy Programmer		Essential tool for programming 2503 Combo Callpoints, 2507 Waterproof Callpoints & 2596 Callpoints. Connects directly to installers PC via serial programming cable that is included.
2533	LRCS 4 Way Relay Board		Provides a low level hardwired interface to third party equipment, can be wired to trigger security alarms, CCTV, building automation, access control and anything that accepts a relay input. This board can be assigned in software to activate specific relays under certain conditions providing either an NC or NO output (selected by hardware) that provides a momentary relay output configurable from 1 – 999 seconds.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.

2730	SnapOn Bed Pad 1 Year (800 x 255)		Place **ON TOP OF THE MATTRESS** Sends **OUT OF BED** message when getting out of bed. Resets **OUT OF BED** when back in bed or via connected monitor. ****Requires 2732 SnapOn Pad Transmitter or 2733 SnapOn Pad Cable to function****
2731	SnapOn Chair Pad 1 Year (420 x 180)		Sends **OUT OF CHAIR** message when getting out of bed. Resets **OUT OF CHAIR** when back in bed or via connected monitor. ****Requires 2732 SnapOn Pad Transmitter or 2733 SnapOn Pad Cable to function****
2732	SnapOn Pad Transmitter		Required by SnapOn Pads. Sends a signal to the 2700 Monitor. ****Replaceable CR2045 battery.****
2602	USB-A to RS232 Serial Converter		Use to connect 2502MC Master Zone Repeater to a PC or Laptop.
2743	1 Gang Wall Box Adaptor Plate		Use when replacing an existing Nurse Call System installation with LRCS. Covers existing 1 gang wallbox and allows 2705 or 2596 Callpoint to fit on top.

All radio frequency (RF) signal transmission and reception distances quoted are indicative only and based on testing carried out under ideal conditions. Actual transmission and reception distances may vary and be dependent on specific environmental conditions.